

Quick instructions

The 3D Hausplaner




Default settings for the standard.cad

Different presets can be made in the 3D Hausplaner, which make it easier to work with a project.

Everything – except the setting of components – is stored in the project file **standard.cad**

Saved (3DHausplanerXXX --> Templates)

You can also create your own template files under your own name.



All setting under:

View – Project – Options – View –
Window – Floor/Layer

e.g. external dimension visible
Grid setting/ Grid capturing –
created views and settings

If you want to change this file or create your own (different) standard.cad, it is useful to draw a project and make all desired settings or check existing settings.

Afterwards, all components of the project are deleted and the file is saved to the template folder.

Either the existing standard.cad file is overwritten, or its own Template created with a new name.

If you want to work with your own template, please start the project with the option “New with template”!

Save Components

In the catalog of the individual components, own components or modified components can be stored

The location is the “own databases” in the 3DHausplanerXXX folder in the program data directory.

Please use the changed **standard.cad** or your own template file and the folder regularly back up ,**own database**’.

The „storing of own components“ is explained in a video tutorial.